

The background features several thick, wavy, light gray lines that sweep across the page. Interspersed among these lines are various circular icons in shades of gray: a camera, a play button, a musical note, a microphone, a double play button, and the Android robot. Dotted lines also connect some of these icons, creating a network-like pattern.

## Start Guide

T-Mobile

**G2x**<sup>™</sup>

with Google


---

## OVERVIEW

This guide provides you with information to get started. For more information and support, please visit [www.t-mobile.com/support](http://www.t-mobile.com/support) where you can:

- Register for **my.t-mobile.com** to check your minutes, pay your bill, upgrade your phone, and change your rate plan.
- Review the User Manual and troubleshooting FAQs.
- View the latest troubleshooting solutions in the Support Forums or ask a question of your own.

You can also access Help information on your phone:

1. From any **Home** screen, tap the **Applications**  icon.
2. Tap **My Account** or **My Device**.

## TABLE OF CONTENTS

Service Activation.....	1	Wi-Fi Calling.....	18
Introducing Your Phone.....	2	Tethering & Wi-Fi Sharing.....	21
SIM Card.....	4	Text Messaging.....	24
Memory Card.....	6	E-mail.....	25
Battery.....	7	Camera & Video.....	29
Power.....	8	Music Player.....	31
Home Screens.....	9	Market.....	32
Applications Screen.....	11	Bluetooth®.....	34
Notification Screen.....	11	Accessories for Your Phone.....	35
Coverage Indicators.....	12	Emergency Dialing.....	36
Call Functions.....	13	Caring for Your Phone.....	36
Contacts.....	14	Tips for Safety.....	37
Volume & Ringtones.....	16	Additional Information.....	38



## SERVICE ACTIVATION

If you are a new T-Mobile® customer and your service has not been activated, simply call Customer Care at **1-800-937-8997** from your landline phone and a T-Mobile Activations representative will assist you.

You will need the following information when activating service:

- Service Agreement and agent code on your Agreement
- Your name, home address, home phone, and billing address  
**Note:** For business and government accounts, please provide the name of your company or government agency, address, and tax ID.
- Your Social Security number, current driver's license number, and date of birth for credit check purposes
- Your choice of T-Mobile rate plan and services (see [www.t-mobile.com](http://www.t-mobile.com) for latest plan information)
- SIM serial number and IMEI number (located on the box bar code label)

By activating service, you acknowledge that you have read, understand, and agree to be bound by each of T-Mobile's Terms and Conditions and your Service Agreement.

## INTRODUCING YOUR PHONE

Congratulations on your purchase.  
Now you can:

- Experience blazing fast Web browsing, searches, and downloads at 4G speeds on T-Mobile's 4G network<sup>1</sup>.
- T-Mobile TV – live and on demand mobile HD TV<sup>2</sup>.
- Voice Actions for Android™ make it faster to find info and get things done.

<sup>1</sup> T-Mobile's HSPA+ 4G network not available everywhere; see coverage details at [www.t-mobile.com](http://www.t-mobile.com). Device has theoretical peak speed of 14.4 Mbps.

<sup>2</sup> Mobile HD TV can deliver a bitrate of 800kbps and 16:9 resolution; the bitrate & resolution you experience will vary based on many factors, e.g., programming, network connection, & device.




## SIM CARD

Your Subscriber Identity Module (SIM) card identifies you to the wireless network. Your phone will not work without the SIM card.

### Insert SIM card and battery


1. Detach your SIM card.



2. Place your fingernail in the notch on the bottom of your phone and lift the back cover off.



3. Lift up the battery to remove. Slide the SIM card into the SIM card slot, as shown.



4. Align the gold contacts on the battery with the gold contacts in the battery compartment. Press the battery into place and replace the battery cover.



## MEMORY CARD

Your phone **does not** come with a microSD memory card. However, you can purchase one to store music, pictures, videos—whatever you want!

### Insert memory card

1. Place your fingernail in the notch on the bottom of your phone and lift the back cover off.
2. Slide the memory card into the memory card slot with the gold contacts facing down toward the phone.



3. Gently press until the memory card clicks into place.

To remove, gently press the memory card into the slot until it clicks. Release the card and it will pop out slightly. Gently remove from the memory card slot.

## BATTERY

### Charge using a wall outlet

On your phone, insert the small end of the charger into the charging port on the bottom of your phone. Plug the other end of the charger into a wall outlet.



### Charge using a computer

You can also charge using the USB cable. Insert the small end of the USB cable into the charging port on the bottom of your phone and the other end into the USB port of your computer.

## Battery Life

Your phone has a convenient **Power Control** widget to help you monitor and maximize your phone's battery life. To add the widget to your Home screen:

1. Touch and hold an empty spot on your Home screen.
2. Tap **Widgets**.
3. Tap **Power Control**.

**Note:** If additional battery options are needed, visit your T-Mobile store for a selection of accessories including car chargers and extra batteries.



## POWER

To turn on your phone, press and hold the **Power / Lock** key on the top.

To turn it off, press and hold the **Power / Lock** key. Tap **Power Off** and then tap **OK**.


## Unlock the screen

1. Quickly press the **Power/ Lock** key on top of your phone to wake your display.
2. Touch the **Lock** icon and slide to the right.

## HOME SCREENS

Your Home screen is wider than you think. Simply swipe your finger right or left to view any of the five Home screens.

You can customize each screen with widgets or shortcuts to your favorite applications.



## Add shortcuts, widgets, and folders to Home screen

1. Navigate to the Home screen where you want to add the item.
2. Touch and hold an empty spot on the screen.
3. Tap **Shortcuts**, **Widgets**, or **Folders**.
4. Tap the item to add.


## Change wallpaper

1. Touch and hold an empty spot on your Home screen.
2. Tap **Wallpapers**.
3. Tap **Gallery**, **Live wallpapers**, or **Wallpapers**.
4. Tap the wallpaper.
5. Adjust the crop box and tap **Save** or tap **Set wallpaper**.

## Remove items from Home screen


1. From the Home screen, touch and hold the item you want to delete.
2. Drag it to the **Trash** icon and release your finger.

## APPLICATIONS SCREEN







While on any Home screen, tap the **Applications**  icon. Touch and slide your finger up or down to scroll through applications. Applications are in alphabetical order.

## NOTIFICATION SCREEN

To view your notifications, touch and drag the **Status** bar down to open the **Notification** screen.



## COVERAGE INDICATORS

	Indicates that your phone is connected to HSPA+ technology
	Indicates that your phone is connected to 3G technology
	Indicates that your phone is connected to EDGE technology
	Indicates that your phone is connected to GPRS technology
	Indicates that your phone is connected to Wi-Fi technology
	Indicates your signal strength (the more bars, the stronger the signal strength)

Device speeds depend on factors such as wireless traffic, topography, weather, and network conditions.

## CALL FUNCTIONS

### Make and end calls

1. From any Home screen, tap the **Phone** icon to open the dialer.
2. Enter the phone number and tap the **Phone** icon to call.
3. To end the call, tap **End**.

### Answer calls

Touch the **Phone** icon and slide to the right.

### Set up voicemail

1. From any Home screen, tap the **Phone** icon.
2. Tap the **Voicemail** icon or touch and hold **1** to call voicemail.
3. Follow the tutorial to set up your voicemail account.

### Reset the voicemail password to the last four digits of your phone number

1. From any Home screen, tap the **Phone** icon.
2. Tap **#793#**.
3. Tap the **Phone** icon.
4. Tap **OK**.

---

## CONTACTS

### Add new contact

1. From any Home screen, tap the **Phone** icon.
2. Tap **Contacts**.
3. Tap the **Menu** key.
4. Tap **New contact**.
5. Enter the contact's name, phone number, and any additional information desired.
6. Tap **Done**.

### Call contact from the contact list

1. From any Home screen, tap the **Phone** icon.
2. Tap **Contacts**.
3. Swipe up and then touch and drag the tab on the right side of the screen to the desired letter, or tap the **Search** key and enter the contact's name.
4. Tap the contact.
5. Tap the desired number to initiate the call.

### Sync account contacts

You can import and sync contacts from your e-mail and social networking accounts like Gmail™, Microsoft® Exchange, and Twitter™. All contacts will display in your phone's contact list. To turn contact sync on or off, follow these steps:

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Accounts & sync**.
4. Tap the account you want to sync contacts with.
5. Tap to select or clear the **Sync Contacts** check box to turn contact sync on/off.

### Import contacts from SIM card

1. From the Home screen, tap the **Phone** icon.
2. Tap **Contacts**.
3. Tap the **Menu** key.
4. Tap **Import/Export**.
5. Tap **Import from SIM card**.
6. Tap the **Menu** key.
7. Tap **Import all**.

## VOLUME & RINGTONES

### Adjust call volume

While on an active call, press the **Volume** key up or down to adjust the call volume.

### Adjust ring volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Volume**.
5. Touch and drag the **Ringtone** slider to the desired level.
6. Tap **OK**.

**Tip:** To set a different volume for your notifications, tap to clear the **Use incoming call volume for notifications** check box and then touch and drag the **Notification** slider to the desired volume.

### Adjust media volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Volume**.
5. Touch and drag the **Media** slider to the desired level.
6. Tap **OK**.

### Adjust touch tone volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Scroll to and tap the **Audible touch tones** and **Audible selection** check boxes to turn on/off touch tone volume.

### Silence ring / notification volume

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap the **Silent mode** check box to silence all sounds except media and alarms.

### Set incoming call ringtone

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Phone ringtone**.
5. Tap the desired tone.
6. Tap **OK**.

## Set notification ringtone

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Sound**.
4. Tap **Notification ringtone**.
5. Tap the desired tone.
6. Tap **OK**.

## WI-FI CALLING

Wi-Fi Calling can improve your coverage and allows you to make phone calls and send messages over a Wi-Fi network (when one is available). Unless your rate plan provides otherwise, Wi-Fi Calling minutes count the same as your T-Mobile wireless calling minutes on your phone bill.

- To use Wi-Fi Calling, you must first turn on Wi-Fi on your phone, connect to a Wi-Fi network, and then turn on Wi-Fi Calling.
- When the Wi-Fi Calling feature is on, your phone displays the Wi-Fi Calling icon on the **Status** bar on the top of your screen.
- To stay on a Wi-Fi call, you must remain in range of the Wi-Fi network. Your call will drop as you leave the


Wi-Fi range. Your phone makes an audible beep and shows a message when a call will drop.

Wi-Fi Calling offers three connection options:

- **Wi-Fi Preferred:** All calls go through Wi-Fi when connected to a Wi-Fi network. Calls drop as you leave the Wi-Fi range.
- **Cellular Preferred:** Calls go over the cellular network, and Wi-Fi Calling is a backup if the cellular network is not available.
- **Wi-Fi Only:** Calls can be made when connected to a Wi-Fi network. If there is no Wi-Fi network, then your calls cannot connect.

## Turn on Wi-Fi and Wi-Fi Calling


1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap **Wi-Fi settings**.
5. Tap to select the **Wi-Fi** check box.
6. Tap **Skip** or **Learn more**, if necessary.
7. Tap the desired network.
8. Enter the password, if necessary, and tap **Connect**.

9. Go back to the Home screen.
10. Tap the **Applications**  icon.
11. Tap **Wi-Fi Calling**.
12. Tap **View Tutorial**, if desired, or tap the **Back** key to clear the alert.
13. At the bottom of the screen, tap the **On/Off** icon to turn on/off Wi-Fi Calling.

When Wi-Fi Calling is on, your phone displays the **Wi-Fi Calling** icon on the **Status** bar at the top of your screen. You can now make phone calls and send messages over the Wi-Fi network.


## Turn Off Wi-Fi Calling

You can choose to turn off Wi-Fi Calling. You can stay connected to Wi-Fi for data usage but not use the Wi-Fi Calling feature. To turn off Wi-Fi Calling, follow these steps:

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Wi-Fi Calling**.
3. At the bottom of the screen, tap the **On/Off** icon to turn off Wi-Fi Calling.

## Set Connection Preference to Wi-Fi or Cellular

**Note:** Wi-Fi Calling must be turned on to change connection preferences.

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Wi-Fi Calling**.
3. Tap the **Menu** key.
4. Tap **Settings**.
5. Tap **Connection preferences**.
6. Tap one of the following options:
  - **Wi-Fi Preferred**
  - **Cellular Preferred**
  - **Wi-Fi Only**
7. Tap **OK**.

## TETHERING & WI-FI SHARING

To use your phone's tethering or Wi-Fi sharing capability, you must have a Tethering and Wi-Fi Sharing service plan.

### Tethering

Your phone has the capability to share its mobile data connection with a single computer via a USB cable.

- Tethering works with Windows® 7, Windows XP, Windows Vista®, and Linux. For more information on tethering with operating systems, go to [www.android.com/tether#usb](http://www.android.com/tether#usb).
- For Windows XP, you must first install the driver on your computer before you can tether. To install the driver, go to [www.android.com/tether](http://www.android.com/tether).
- When you connect your phone to your computer using the USB cable, you can either tether or access files on the memory card but you cannot do both. If you want to use your computer to access the memory card, then you must not turn on tethering.

## Wi-Fi Sharing

You can share the mobile data connection from your phone with other devices by turning your phone into a portable Wi-Fi hotspot.

- When your phone is serving as a Wi-Fi hotspot, you cannot access the Internet via its Wi-Fi connection.
- For more information, go to [www.android.com/tether#wifi](http://www.android.com/tether#wifi).

## Tether Your Phone

1. Connect your phone to your computer using the USB cable.
2. On your phone, tap the **Back** key.
3. Tap the **Menu** key.
4. Tap **Settings**.
5. Tap **Wireless & networks**.
6. Tap **Tethering and portable hotspot**.
7. Tap to select the **USB tethering** check box.

Your phone starts sharing its wireless network data connection with your computer via the USB connection.

## Turn on Wi-Fi Sharing


1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap **Tethering and portable hotspot**.
5. Tap to select the **Portable Wi-Fi hotspot** check box.

Your phone starts broadcasting its Wi-Fi network name (SSID), allowing you to connect up to eight Wi-Fi enabled computers or other devices. Your phone's default SSID is **AndroidAP**.

6. Tap **Portable Wi-Fi hotspot settings**.
7. Tap **Configure Wi-Fi hotspot**.
8. Enter a new name for the SSID.
9. Tap the **Security** drop-down menu.
10. Tap **WPA2 PSK**.
11. Tap the **Password** field and enter your password.
12. Tap **Save**.
13. On your computer, open the application you use to connect via Wi-Fi and select your phone's SSID.

## TEXT MESSAGING

### Access messaging

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Messaging**.


### Delete a message or message thread


1. While viewing your message or while in your message inbox, touch and hold the message.
2. Tap **Delete message** or **Delete thread**.
3. Tap **OK**.

## E-MAIL

Your phone comes with e-mail capability so you can stay connected with Gmail™, Microsoft® Exchange, Yahoo!®, Windows Live® Hotmail®, AOL®, and other popular e-mail providers.

### Set up Internet e-mail

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Email**.
3. Tap **Others**.
4. Enter your e-mail address and password.
5. Tap **Next**.
6. Enter a name for your account (optional).
7. Enter the name you want displayed on outgoing messages.
8. Tap **Done**.



### Set up Corporate/work e-mail

Contact your company's IT department if you need more help. This feature works with Microsoft® Exchange e-mail servers only.

1. From any Home screen, tap the **Applications**  icon.

## 2. Tap **Email**.

**Note:** If you have already set up an e-mail account, tap the **Menu** key, tap **Accounts**, tap the **Menu** key again, and then tap **Add account**.

## 3. Tap **MS Exchange**.

4. Enter your e-mail address and password.

5. Tap **Next**.

6. Enter the domain, username, and server, as needed.

7. Tap **Next**.

8. Adjust the e-mail checking frequency, synchronization schedule, and notification options, if desired.

9. Tap **Next**.

10. Enter a name for your account (optional) and tap **Done**.

## Create a Gmail™ e-mail account

1. From any Home screen, tap the **Applications**  icon.

2. Tap **Gmail**.

3. Tap **Next**.

4. Tap **Create**.

**Note:** If you already have a Google account, tap **Sign in** and enter your login information.

5. Enter your first name, last name, and the username you want on your account.

6. Tap **Next**.

**Tip:** Tap the **Back** key to close the on-screen keyboard.

7. Enter a password.

8. Tap the **Confirm password** field and re-enter the password.

9. Tap **Next**.

10. Tap the **Security question** drop-down menu and tap the desired question.

11. Enter your answer and a secondary e-mail address (optional).

12. Tap **Create**.

## Add additional e-mail accounts

1. From any Home screen, tap the **Applications**  icon.

2. Tap **Email**.

3. Tap the **Menu** key.

4. Tap **Accounts**.

5. Tap the **Menu** key again.

6. Tap **Add account**.

7. Tap **Other**.

8. Enter your e-mail address and password.


9. Tap **Next**.

10. Enter a name for your account (optional).

11. Enter the name you want displayed on outgoing messages.

12. Tap **Done**.

## Access your mailbox

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Email**. The inbox for the last e-mail account you viewed will display.
3. To change to a different account, tap the account name at the top of the screen.
4. Tap the desired account.

## Send e-mail

1. While in your mailbox, tap the **Menu** key.
2. Tap **Compose**.
3. At the **To** field, enter the e-mail address.  
**Tip:** Tap the **Back** key to close the on-screen keyboard.
4. Enter your subject and message.
5. Tap **Send**.


## Delete e-mail accounts

1. While in your mailbox, tap the **Menu** key.
2. Tap **Accounts**.
3. Touch and hold the account that you want to delete.
4. Tap **Remove account**.
5. Tap **OK**.

## CAMERA & VIDEO

### Take a picture

Pictures are saved to **Applications > Gallery**.


1. From any Home screen, tap the **Applications**  icon.
2. Tap **Camera** to open the capture screen in landscape mode.
3. Frame your subject.
4. Tap the **Camera** icon to capture.

### Send a picture

1. Take a picture.
2. Tap **Share**. If you don't see **Share**, tap the picture to display additional options.
3. Tap one of the following and continue on to send your picture:
  - **Bluetooth**
  - **Email**
  - **Gmail**
  - **Messaging**
  - **Picasa**

## Record a video


Videos are saved to **Applications > Gallery**.

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Camera** to open the capture screen in landscape mode.
3. Touch and drag the **Camera/Video Mode** slider to video.
4. Frame your subject.
5. Tap the red **Record** icon to start recording.
6. Tap the blue **Stop** icon to stop.

## Send a video


1. Record a video.
2. Tap **Share**. If you don't see **Share**, tap the picture to display additional options.
3. Tap one of the following and continue on to send your video:
  - **Bluetooth**
  - **Email**
  - **Gmail**
  - **Messaging**
  - **YouTube**

## Adjust settings

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Camera** to open the capture screen.
3. Tap **Settings**. If you don't see **Settings**, tap the picture to display additional options.
4. Tap the desired settings to adjust.

## MUSIC PLAYER

### Access the music player


1. From any Home screen, tap the **Applications**  icon.
2. Tap **Music**.

### Transfer music from computer

1. Connect your phone to your computer using the USB cable.
2. On your phone, from any Home screen, tap the **Menu** key.
3. Tap **Settings**.
4. Tap **SD card & phone storage**.
5. Tap to select the **Mass storage only** check box.
6. Tap **Turn on USB storage**.
7. Tap **OK**. The Removable Disk window opens on your computer.

8. Click **Open folder to view files using Windows Explorer** and click **OK**.
9. Locate the file(s) on your computer that you want to copy.
10. Copy and paste the file(s) into the memory card drive.
11. When finished, on your phone tap **Turn off USB storage** and disconnect your phone.

## Play music

1. From any Home screen, tap the **Applications**  icon.
2. Tap **Music**.
3. Locate and tap the song.

## MARKET

Download fun games and cool apps from the Android Market™.

### Browse the T-Mobile channel

1. From the Home screen, tap the **Applications**  icon.
2. Tap **Market**.

**Note:** If you do not already have a Gmail account set up, follow the on-screen instructions to set one up at this time.

3. Read the Android Market terms of service and tap **Accept**.
4. Tap **T-Mobile** to view applications recommended by T-Mobile.

## Install applications

1. While browsing the marketplace, tap the desired application.
2. Tap **Install**.
3. Tap **OK** to allow the application access, if necessary.
4. When the application has successfully installed you will see a **Notifier** icon on the **Status** bar.
5. Touch the **Status** bar and drag down the **Notification** screen. Tap the application **Notifier** icon to complete additional installation steps or to launch the application. You can also launch the application from the icon in Applications.

Full access to Web requires the purchase of a qualifying data plan. Separate additional charges may apply for downloads; actual content available for download may vary.

## BLUETOOTH®

Your phone comes with Bluetooth technology, a wireless technology that enables a data connection between your phone and a Bluetooth wireless headset and other Bluetooth devices (sold separately).

### Prepare Bluetooth headset

To pair your phone with a Bluetooth headset, make sure that your headset is fully charged and that you set the headset into pairing mode. See your Bluetooth headset's manual for more information.

### Turn on Bluetooth and pair with headset

1. From any Home screen, tap the **Menu** key.
2. Tap **Settings**.
3. Tap **Wireless & networks**.
4. Tap **Bluetooth settings**.
5. Tap to select the **Bluetooth** check box and turn it on. A list of available Bluetooth devices displays.
6. Tap your headset in the list.
7. Enter the PIN or passcode, if requested.
8. Tap **OK**.

## ACCESSORIES FOR YOUR PHONE

Whether you are looking for a charger, a fashionable carrying case, a Bluetooth® headset or just want to browse for fun extras for your phone, T-Mobile is the place to shop for accessories. Here are a few examples...



Charger



Bluetooth Headset

To purchase accessories for your phone, visit [T-Mobile.com](http://T-Mobile.com), call 1.800.204.2449 or visit your nearest T-Mobile store.

Accessory selection subject to change and may vary by location.

## EMERGENCY DIALING

While all phones are equipped with 911 emergency calling, this phone may or may not permit its location to be approximated during a 911 call.\*

\* Availability of this feature depends on upgrades to the (a) wireless network and (b) 911 calling system that are required to be installed by the local 911 response agency or public safety answering point (PSAP); these upgrades may not be available everywhere within our wireless coverage area or your roaming area. This approximation of the phone's location and the transmittal of location information are subject to emergency situations, transmission limits, network problems/limitations, interconnecting carrier problems, your phone, buildings/tunnels, signal strength and atmospheric/topographical conditions, and may be curtailed, interrupted, dropped or refused. The phone's approximate location is transmitted to the local 911 response agency or PSAP while the call is in progress; this approximation is intended solely to aid the PSAP in dispatching emergency assistance or to limit the search area for emergency services personnel. You should not rely solely on a phone for essential communications (such as a medical or other emergency). Please see T-Mobile's Terms and Conditions and Privacy Policy for additional service restrictions and details.

## CARING FOR YOUR PHONE

### MAKING IT LAST

Your phone is a complex electronic device; think of it as a mini-computer. Here are some hints that will help you extend the life of your new phone.

**Phones aren't cheap, so keep yours in a safe place.** Keep the phone away from

children who want to see if the phone sinks or floats, and away from dogs that find plastic-coated products to be irresistible chew toys.

**Water will damage your phone and accessories.** Even a small amount of water from a soda in your car cup-holder, melting snowflakes, tears of joy, squirt-gun crossfire, or steam from the kitchen or bathroom can damage your phone.

**Use only batteries and accessories from the original manufacturer of your phone.** Non-approved accessories can damage you or your phone and shorten the phone's life. Hint: If it's being sold out of someone's car trunk, walk away.

**If your charger or any other accessory is damaged, replace it or take it to a qualified service dealer.** Do not attempt to operate your phone charger if it has received a sharp blow, been dropped, thrown from a speeding motorcycle, or is otherwise damaged; doing so may damage your phone.

## TIPS FOR SAFETY

Check with your doctor if you have a pacemaker or hearing aid to ensure that cell phone usage is safe with your device. If you have questions about the interaction of cellular radio frequency and any other electronic equipment, ask the manufacturer of the equipment if cell phone radio frequencies will disrupt the equipment's performance.

**When you are driving, T-Mobile encourages you to use your phone in a safe and sensible manner. Here are a few tips:**

- Assess road conditions before answering. Your safety is more important than any call.
- Prepare your hands-free headset, if you have one, or turn on your speakerphone option before you start moving.
- If your phone rings and you discover it's in the back seat, do NOT crawl over the seat to answer it while driving.
- Program frequently used numbers into your speed dial for easy one-select dialing.
- Remember that laws prohibiting or restricting the use of a mobile phone while driving may apply in your area.

## **ADDITIONAL INFORMATION**

Use of some features or services may incur separate, additional charges and/ or require a qualifying data plan.

**Wi-Fi:** Device will not transition between Wi-Fi and the wireless network. Devices using wireless connections may be vulnerable to unauthorized attempts to access data and software stored on the device.

**Wi-Fi Calling:** This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

**Messaging/Data:** You will be charged for all data sent by or to you through the network, regardless of whether received. Character length/file size of messages/attachments may be limited. T-Mobile is not liable for content of messages/attachments or for any failures, delays or errors in any T-Mobile generated alerts or notifications. Your data session, plan, or service may be slowed, suspended, terminated or restricted if you use your service in a way that interferes with or impacts our network or ability to provide quality service to other users, if you roam for a significant portion of your usage, or if you use a disproportionate amount of bandwidth during a billing cycle. You may not use your plan or device for prohibited uses.

**Downloads/Applications:** T-Mobile is not responsible for any third party content or Web site you may be able to access

---

using your phone. Additional charges may apply; not all downloads available on all phones. You obtain no rights in downloads; duration of use may be limited and downloads may be stored solely for use with your phone. T-Mobile is not responsible for any download lost due to your error. T-Mobile is not responsible for Apps, including download, installation, use, transmission failure, interruption or delay, third party advertisements you may encounter while using an App, alterations any App may make to the functionality of your device, **including any changes that may affect your T-Mobile plan, service, or billing**, or any content or web site you may be able to access through an App.

See brochures and the **Terms and Conditions (including arbitration provision)** at T-Mobile.com, for rate plan information, charges for features and services, and restrictions and details, **including important limitations on availability and reliability of 9-1-1 emergency service when using Wi-Fi calling.**

The Bluetooth® word mark and logo are owned by the Bluetooth SIG, Inc. and are used by T-Mobile under license. T-Mobile and the magenta color are registered trademarks of Deutsche Telekom AG. web2go is a registered trademark, and T-Mobile G2x is a trademark, of T-Mobile USA, Inc. Google and the Google logo, Google Voice, Google Search, Gmail, Google Talk, Android, Android Market are trademarks of Google Inc. © 2011 T-Mobile USA, Inc.



T-Mobile®